


CONTODAT
automatic



EBERHARD & CO

Manufacture Suisse d'Horlogerie depuis 1887

USER MANUAL



1887

The Eberhard & Co. watch manufactory was founded by Georges-Lucien Eberhard at La Chaux-de-Fonds back in 1887. Ever since, the venture has specialised in the making of chronographs.

In this capacity, it has attained a highly respected position in the world of high-grade watches. With the introduction, at a later stage, of sportively elegant watches it has furthermore augmented this status of the Eberhard & Co. brand name.

Eberhard's success story is backed by consistent deployment of advanced technology, meticulous craftsmanship and, not least, by observing that long tradition of superior workmanship which has made Swiss watchmaking a household name.

Today, with well over a century gone by, watches by Eberhard & Co. continue to stand for that high-grade quality and those excellent virtues which will please even the most demanding of connoisseurs.

Today the historic Eberhard & Co. headquarters, at 73 Avenue Léopold-Robert, house the brand museum, which can be visited by appointment.

CONTODAT *automatic*



"Contodat Automatic" is a mechanical watch with automatic winding, whose design is inspired by a model launched by Eberhard & Co. in the 1970s, originally available only in a chronograph version. The watch features a very distinctive dial that includes a seconds counter at 9 o'clock, with a vibrant orange contrasting hand, and, symmetrically at 3 o'clock, the unique trapezoidal date display, a direct reference to the vintage model. Presented with an elegant dial alternating "soleil" and "azuré" detailing, the watch is designed with an integrated steel bracelet, featuring both polished and satin finishes, and equipped with the exclusive 2CLICK® push-button clasp.

We hereby guarantee your Eberhard & Co. watch against any defect in manufacture or materials for a period of 24 months from the date of purchase, subject to normal conditions of use.

This guarantee does not cover:

- damage, including indirect damage, caused by shocks, falls or incorrect use of the watch
- the glass or any other parts of the watch subject to normal use
- watches whose reference or matriculation number has been worn away or altered, or Shield Cards that have not been correctly activated
- work carried out on the watch or strap by non-authorized persons or alterations made to the watch that do not respect its original configuration
- damage caused by the failure to check the watch's water resistance
- possible shipping and insurance costs

To have your Eberhard & Co. watch serviced or repaired, please contact one of our service centres or an authorised retailer and present your Shield Card, filled in and complete with the activation PIN.

We recommend a check-up or overhaul of the movement on average every 3 years, depending on the conditions of use.

For more information, please visit **eberhard1887.com**



- A Hour hand
- B Minute hand
- C Small seconds hand
- D Date
- E Crown

FEATURES

The “Contodat Automatic” is a watch with a self-winding mechanical movement characterised by a 39 mm stainless steel case. It features a screw-down crown, a sculpted sapphire glass with anti-reflective treatment, and a screw-down caseback personalised with the engraving of the Latin inscription “WHERE YOU WILL BE, THERE I WILL BE”).

The hands, as well as the hour markers on the dial, are highly luminescent to ensure optimal visibility at night.

This collection is available in the following version:

- Stainless steel case with integrated stainless steel bracelet, equipped with the 2CLICK® clasp. Water-resistant up to 100 m.

EFFECTS FROM MAGNETIC FIELDS

It is recommended that you do not leave your watch near electronic devices (e.g., televisions, cell phones, refrigerators, microwave ovens, radio alarms, etc.), as they can emit magnetic fields – even at short distances – that may magnetize several components of the mechanical movement, causing variations in timekeeping accuracy.

In case of magnetization, the movement must undergo a simple demagnetization procedure.

CARE OF WATERPROOF WATCHES

The “Contodat Automatic” model can be worn in the shower, for diving, and snorkeling, but it is not designed for deep-water diving.

Important: always ensure that the crown is properly secured before any contact with water.

After exposure to seawater, gently rinse your watch with fresh water.


Be careful not to pull out the crown when the watch is wet.

It is recommended to have the watch's waterproofing checked annually at one of our authorized service centres, which will inform you if the seals need to be replaced.


OPERATING THE CROWN




POSITION A - Screw-in crown, water resistance guaranteed.



POSITION B - HAND-WINDING OF THE WATCH – To unscrew the crown turn it counterclockwise. When it is unscrewed, turn it clockwise to transmit the manual charge to the movement. If your “Contodat Automatic” has not been worn for some time, the automatic movement has to be wound manually to immediately obtain a sufficient power reserve and ensure the accurate functioning of the watch.



POSITION C - RAPID DATE-SETTING – Pull the crown out to the first notch. By turning the crown clockwise, you can adjust the date indicator.



POSITION D - TIME SETTING – Pull the crown out to the second notch. In this position, you can adjust the hours and minutes.

IMPORTANT

To set back the crown ④, push it gently against the watch case while turning it clockwise until it is fully screwed in again.

Before diving make sure that the crown ④ is locked (A position). Only under these conditions can water resistance be guaranteed.



CELEBRATE YOUR TIME

EBERHARD1887.COM